

# Assembly, Operating & Maintenance Instructions

## buroseating


Attention: Please remove all items from the carton, and verify all pieces before assembly.


## **BURO VELA Mesh MB Chair**





Parts List		
KEY	QTY	DESCRIPTION
Α	5	Castors
В	1	Base
С	1	Gas Lift
D	1	Seat
Ε	1	Back
F	2	Allen Wrench
G	6	Arm Screws & Washers (35mm)
G1	3	Back Screws (22mm)
Н	1	Optional arms





## Care & Maintenance

### **GENERAL CARE**

- To maintain the appearance of non-upholstered parts wipe the surface with a clean cloth dampened with a mild detergent solution.
- · Do not remove any parts for separate cleaning.
- Do not saturate the fabric or interior with water or other cleaning liquids.
- · Do not shampoo clean.
- · Do not clean with hot water extraction machine.
- Do not clean with onsite drycleaning machine.
- Protect from direct sunlight, heat and weather.

## FABRIC UPHOLSTERY CARE

- Wipe with a clean cloth dampened with a mild upholstery detergent solution.
- $\boldsymbol{\cdot}$  A soft bristle brush may be used to remove ingrained soil.
- Spot clean as above.
- Treat spills and stains as soon as possible.
- Persistent stains may require treatment by a professional cleaner.
- $\cdot$  May be cleaned with dry powder cleaners.
- · Allow to dry thoroughly before reuse.

# Step 5

## Upholstery & Foam Specs\*

## FOAM

Flame Resistant: Ca117 Section A Part I & Section D Part II

## UPHOLSTERY: FABRIC

Flame Resistance: Ca117 Section E Class I

\*This applies only to standard Buro Seating stock. Any customer specified upholstery may not meet these specifications.

## **Preventative Maintenance & Warning!**

- · Use this product only for seating one person at a time.
- Do not use this chair as a step stool/ladder.
- · Do not sit on any part of the chair except the seat.
- · Do not use this chair on uneven floor surfaces.
- $\boldsymbol{\cdot}$  Do not interfere with the operating of the gas lift.
- $\boldsymbol{\cdot}$  Do not use chair unless all bolts, screws and knobs are tight.
- $\bullet$  At least every six months check all bolts, screws and knobs to ensure they are tight.
- If any parts are missing, broken, damaged or worn do not use the product until repairs are made using factory authorised parts.
- · Dispose of packaging properly.
- · Plastic bag is not a toy.
- Do not use plastic bag as a head covering as it may cause suffocation.
- Failure to follow these warnings could result in serious injury.



